digital™

AV-PC9NA-TE

Read This Before Installing Your IEEE488 Bus Converter (IEZ11)

IEZ11 Micro Code

The IEZ11 software Version 1.0 runs only on a SCSI488/D with micro code revision 4.1 or higher. The IEZ11 software does not work with SCSI488/D prototypes. All SCSI488/Ds ordered through normal channels have the correct version of the micro code installed. You can determine the micro code revision from the Installation Verification Procedure (IVP). To run the IVP enter the following command line:

```
$ RUN  SYS$SYSTEM:IEZ11$IVP.
```

Product Installation

Before installing your hardware and software, first read the *IEZ11 Hardware Installation Guide* and *IEZ11 Software Installation Guide*, as well as the release notes, supplied on the software media, to familiarize yourself with the product. Pay particular attention to configuration and termination rules.

License Installation

Before installing your IEZ11 software Version 1.0, you must first install the license. You can install the license at the DCL level by entering the following command line:

```
$ @SYS$UPDATE:VMSLICENSE
```

Servicing the IEZ11

Your IEZ11 contains no internal user-selectable or user-serviceable parts. The supply voltage rating is set at the factory. All repairs and modifications must be performed by qualified personnel.

© Digital Equipment Corporation. March, 1990. All rights reserved.